

INSTRUCTION MANUAL

Please read the manual carefully before using the device. Pictures and products in the manual for reference only.

1.Before starting

1. Check if the watch is the correct model and has complete accessories in the package.
2. Prepare a 4G LTE SIM card, can ask for your dealer if have any questions.(Please turn off the power before installing the SIM Card)
3. It is necessary to activate data flow, GPRS and caller display functions.
4. Download the mobile APP in your cell phone and if you can't find it please ask the seller for the way of downloading.

2.Install the Nano-SIM card.

1. Make sure the device is off the power.
2. Take off the SIM card protective cover.
3. Place a Nano-SIM card into the SIM tray and make sure that the card's chip part is on the up side. Then put the tray back in and install the protective cover.(If the model does not have a SIM tray, just directly insert the Nano-SIM card into the slot and make sure that the card's chip part is on the up side.)

3.Switch on and off


Switch on:

If the device is turn off, long press the power button to turn on the device.

Shutdown:

- 1: Enter the settings, choose the power off option.
- 2: When the device is crashed, you can use remote shutdown from Mobile app.
- 3: If not put a SIM card, long press the power button to turn off the device.

4.Function details



Button (1) is about Power,SOS and hang up and health monitor

function.

Power: long press this button for 5 more seconds to switch on or off.

Time clock: press once and the device will announce current time.

Hang up: You can press the button to reject the incoming call.

Health monitor: Quickly,three times press the button into heart rate and blood pressure monitor. Four times rapid press to launch temperature monitor.

Caution:

When power is on, you can press the power button one time quickly to check the connection status.If then the indicator is green, the connection is normal.If it is red, the connection failed.

Button (2) is about voice chat incoming call answer and speed dial

function.

Voice chat: hold to record voice message and release to send to the receiver on app

Answer: press this button when call is incoming

Speed dial: press twice quickly then call the contact 2, and three times quick press to dial the number of contact 3(who you added into the contacts before)

Indicator status

1. Red: when the battery is lower than 20%. The indicator will turn red and then twinkle every 5 seconds.

2. Green: when there is an incoming call, the indicator will turn green and twinkle quickly. And the indicator will stay green when charging is over and the charge port is still on.

IMPORMANT

Health monitor: when the indicator twinkles from red to green quickly, it means the monitoring of heart rate and blood pressure finished. If the monitoring is OK, the indicator will stay in green for 3 seconds.If not, it will stay in red.

5.Download the APP


5.1

- 1: Scan the QR code below to download the APP and install directly.
- 2: Enter the device information option in the watch and find the QR code to scan and download.



5.2 Register and login in.

Please follow the steps in the APP to register and login in.



5.3Bind with the device.

Login in the APP and find the correct device.The correct device type is SMART WATCH.Enter the registration code to bind with device.

About the registration code:

- (1) Scan the QR code on the back of device or manually enter the 15 numbers length code
- (2) Enter the device information page and find the registration code option,scan or manual input.

6.Functions

Location: GPS + LBS +WIFI hotspots Location real time on Map.

Trace: Find the trace in APP.

Safety area: Set fence(safety area) in the device(Max 3 fences),And notify you in APP when watch wearer reach or out of the appointed area.

Contact: Setting up maximum 15 members of your friends or relative in APP.

SOS: 3 emergency contacts can be set. Press the SOS BUTTON(The button on some models is the power button) for 3 more seconds and it will make an emergency call to the appointed contacts in turns.If there is no one answering, it will continue to dial twice in turns and stop.

Remote monitor(voice): Set the function in APP.After the monitor is turned on, the watch will dials the set number.This calling is one-way.Only You can monitor the voice and sound of the watch wearer.

White list: Turn on this function and the watch only receives the call from the contacts.It will block all other calls.

Alarms: Set 3 alarm clocks

Voice chat: Real time chat between the device and the APP. APP can text or send 15s voice message to the device.And device can read one unread message each time and only send voice message.

Do not disturb: Set 4 periods in one time.Block all calls and keep silent mode in this appointed period.

What is in Device Information:

1. Registration code: Scan it to register device.
2. APP download: Download the Beesure GPS APP

Members: Show the account of family members who is bind with with the device.

Remote shut down: Remote shutting down order to the watch when it is power on.

Remote restart: Send a remote restarting message to the watch.And restart the device.

7.Trouble shooting

If the device can not connect to the server in your first time of using, and on the APP shows the device is out off line.Please check the following conditions:

- 1) Your SIM card is 4G and network is normal or not.
- 2) Data flow service is turned on and normal or not.
- 3) The ip and port,or the IMEI is correct or not.The IMEI code on the device shall be same as the factory code.You can get the code by send message **pw,123456,ts#** to the watch.(The watch has a SIM card.And the message is texted **in ENGLISH**).
- 4) If still not working, please ask the seller for more details and help.
- 5) If you can not register, there are 2 problems usual:
 1. The code of device does not exist or it has registered before, under this condition you must ask for your seller for help.
 - 2.Account has registered before.Under this condition, you just change this account is OK.